

## **General Assembly**




Operation Manual TR90/85	M051- 00K20-A371	
Service Manual TR90/85/T9i	M051-00K60-A013	


# **Console Assembly (1of 3)**

TR9000 Console Assembly		TR9000 Overlay Bezel	
AK60-00014-0001	Eng/Met	AK60-00011-0001	Eng/Met
AK60-00014-0003	Ger/Met	AK60-00011-0003	Ger/Met
AK60-00014-0004	Spn/Met	AK60-00011-0004	Spn/Met
AK60-00014-0006	Jap/Met	AK60-00011-0006	Jap/Met
AK60-00014-0007	Frn/Met	AK60-00011-0007	Frn/Met
AK60-00014-0008	Itl/Met	AK60-00011-0008	Itl/Met
AK60-00014-0009	Dut/Met	AK60-00011-0009	Dut/Met
AK60-00014-0010	Por/Met	AK60-00011-0010	Por/Met




# Console Assembly (2 of 3)







#### Console Assembly (3 of 3)




# **Motor Cover, Leveler, and End Caps**




## **ERGO Bar and Upright Assembly**




# Accessory Trays




#### Belt, Deck, and Rollers




# **Lifesprings & Anti-Static Tinsel**






## **Lift Frame Assembly**




#### **Lift Motor and Home Switch**


Lift Motor OK60-01094-0000 (120v) OK60-01166-0000(220v/60Hz) Clevis Pins 0017-00007-0214 Clevis Clips 0017-00007-0208 Home Switch 0017-00032-0195

## **Drive Motor Assembly**





#### Wax Motor, Wax Bag, and Wax Nozzle & Bracket






#### **Sensors**







#### **Rear Roller Cover Guards**




#### **DC Controller and ON/OFF Switch**





## **Line Filter Assembly and Line Cord**



0017-00003-0952 120v/60Hz 12' Domestic

#### **Cables**

